1D and 2D Modelling of Bends and Hydraulic Structures

Bill Syme

BMT WBM TUFLOW

Form Losses

- Energy dissipated as heat due to changes in velocity magnitude and direction
- Pronounced at
  - Bends
  - Flow constrictions (structures)
- Form loss coefficient
  - Proportion of dynamic head ($V^2/2g$) lost
  - V = 1m/s; Dynamic Head = 0.05m
  - V = 4m/s; Dynamic Head = 0.82m

BMT WBM 2 TUFLOW

Right-Angled Bend 1D vs 2D







BMT WBM 3 TUFLOW

River Bends

- 4 m/s
- 20 m deep
- 0.4m superelevation at bend

BMT WBM 4 TUFLOW

2D vs 3D?



BMT WBM 5 TUFLOW

Bends - Conclusions 1D and 2D Approaches

- 1D
  - Apply extra losses by
    - Form loss coefficient, or
    - Increasing Manning's n
  - Do not model superelevation
- 2D
  - Form losses inherent / Models superelevation
  - However
    - Are model elements too coarse to simulate all losses?
    - Are there losses in the vertical plane? (Helicoidal circulations)
  - Additional form losses may be required

BMT WBM 6 TUFLOW

Hydraulic Structures

- Hydraulic Structures
  - Bridges and Embankments
  - Large Culverts
- Hydraulics is Complex (3D)
  - 1D: Traditional Approach
  - 2D: Looks impressive, but is it accurate?
  - 1D/2D: Best of both?

BMT WBM 7 TUFLOW

2D: Looks impressive, but is it accurate?



BMT WBM 8 TUFLOW

1D: Traditional Approach Uses Contraction/Expansion Losses



BMT WBM 9 TUFLOW

2D: No Contraction/Expansion Losses?



BMT WBM 10 TUFLOW

2D Scheme Modifications
(2d_fc or 2d_fcsh layers)



BMT WBM 11 TUFLOW

2D Layered Adjustments
(2d_lfcsh layers)



BMT WBM 12 TUFLOW


2.86 m
2.86 m
2.42 m
2.86 m
0.7 m/s
2.0 m/s
0.8 m/s
Water Surface Profiles - Outlet Controlled
1D Model
Upstream of Culvert
Downstream of Culvert
Water Level (m)
Distance (m)
BMT WBM
13
TUFLOW


Water Surface Profiles - Outlet Controlled
1D Model
2D Model (Culvert as 2D Cells)
Upstream of Culvert
Downstream of Culvert
Water Level (m)
Distance (m)
BMT WBM
14
TUFLOW


So 2D isn't perfect!
What are our options?
Don't use 2D!
Adapt 2D Solution
Insert 1D Solution
BMT WBM
15
TUFLOW

"Calibrating" 2D Structures



- For example, if we apply a 0.2 FLC, ie. add $0.2*V^2/2g$ energy loss



BMT WBM

TUFLOW

"Calibrating" 1D Culvert linked to 2D



- Culvert as 1D Element
  - Reduce Outlet Loss Coefficient by 0.2



BMT WBM

17

TUFLOW

1D/2D Link Options



- SX Link
- HX Link (Preserves momentum)



BMT WBM

18

TUFLOW

Modelling Culverts - Conclusions

- Culvert as 2D Cell(s)
  - 2D solution models 70 to 80% of losses
  - Need 20 to 30% additional form losses
- Culvert as 1D Element
  - Over predicts losses by 0 to 70%
  - Small – 0% over prediction
  - Large – up to 70% over prediction
  - Reduce inlet / outlet losses of 1D element(s)

BMT WBM 20 TUFLOW

Embankments / Levees (Weir Flow)

- Approach
  - Test submergence across cell side
  - BC Weir equation if unsubmerged
  - No adjustment if submerged
- Thin Weir Test





BMT WBM 21 TUFLOW

Oblique Weirs

- Flow oblique to grid
- Weir at 45° test
- Correct using weir coefficient





BMT WBM 22 TUFLOW

Real World Example

- Bruce Hwy, Eudlo Creek, Qld – 1998
- Bridge Piers and Deck
- Weir flow over levees
- Nested 1D Elements
  - Pipes
  - Weir flow over bridge deck



BMT WBM 23 TUFLOW

Real-World Applications

- 2D Schemes need to:
  - Adjust cell: widths / flow areas / wetted perimeters
  - Set cell obverts (lids)
  - Apply additional form losses
  - Handle unsubmerged weir flow
- Nested 1D Elements may need to:
  - Reduce inlet/outlet loss coefficients (to prevent over prediction of losses)

BMT WBM 24 TUFLOW

Conclusions

- 2D contracts and expands flow lines
  - Inherently models form losses
- May not model 100% of losses
  - Need ability to add form losses (calibrate)
- Need momentum and viscosity terms
- Linking 1D structures into 2D
  - Useful when the structure is small
  - Large structures (relative to 2D cell size) may over predict losses
    - May need to reduce inlet / outlet losses (calibrate)
- Check and UNDERSTAND your results

BMT WBM 25 TUFLOW